

CHEST DESIGNER

USER'S MANUAL

Friday, May 18
Pascal Leray
pascalleray.ftd@free.fr
<http://pascal.leray.free.fr>

SUMMARY :

Chest designer is dedicated to organbuilders who want to design, control and built directly their chests. Only pipe dimensions are needed as inputs. Chest designer outputs provides .DXF files which can control automated drilling machine tools, easily affordable with “service bureau” companies.

Chest Designer can display chests and whole organs in 3D.

All kind of chests can be designed : tracker chests, diatonic, chromatic, mixtures, and so on.

For unit chests, chest designer provides pallet magnet sizes and number per size. Hole diameter security can be defined by the organbuilder.

Moreover, pipe dimensions can be given pipe by pipe or by octave. Use the

CHEST FILE FORMAT :

Chest format Keywords : Dimensions are given in millimeters.(could be changed if necessary)
ENGLISH

UTenUT : allows octave pipe dimensions definition.

CENTRAL HOLE : Hole position for a pilot supporting the middle of the chest.

STOP : Defines a new register on the chest.

DIATONIC : for diatonic or chromatic stops. Followed by the total stop length.

SLIDER : 1 register slider; 2 : Master register slider (all other register stops will be aligned on this one).

NPIPES : Number of pipes of the above stop

PIPE1 : defines the first pipe number

INCX : defines the increment of the stop : diatonic or chromatic : if INCX is negative, pipes are computed from right to left left to right otherwise.

SHAPE: (don't forget the ':' character) Pipe shape : SQUARE or ROUND

XY0 : X and Y position of the first pipe of the stop.

Then follows the successive dimensions ; (millimeters)

PIPE DIAMETER

HOLE DIAMETER (diameter of the hole under each pipe.

False chest diameter : pipe diameter at 12cm from the chest (can be changed)

HEIGHTS : Pipe heights

STOP : next register and so on.

NOTA 1: CHEST DESIGNER can also compute MIXTUR chests. :

Write the keyword “MIXTUR” before the “STOP” keyboard. Next “MIXTUR” and “STOP” keywords define the different mixture ranks.

NOTA 2 : Pipe dimensions can also be given octave by octave, or pipe by pipe.

CONTROLS :

FILE

New : open a void chest

Open Chest : Opens a chest file (.dat).

Add Chest : add a previously defined chest. Enter the X Y Z positions of the added chest. These positions can be changed by using the control : Display/Display Chests.

Open Organ : .ORG FILES : opens an organ, defined by several chest files. Org files can be made of chests and air pipes.

Save : Saves a full organ, with all his windchests and their spatial X Y Z positions with the current name..

Save as : Saves a full organ with another name.

Export DXF : export a chest with his current name : given an XXX.dat file, creates XXX.som file for the upper part of the chest, XXX.fs for the file chest file and XXX.mix file for a possibly mixture stop.

Not available on the free version. Please send your .dat file, and I'll return a .dxf file.

Print

Printing Scale

File	Edit	Display	View	Creat
New				Ctrl+N
Open Chest				Ctrl+O
Add Chest				
Open Organ				
Save				Ctrl+S
Save as...				
Export DXF				CTRL+D
Print...				Ctrl+P
Printing scale				
Print Preview				
Printing Setup				
Fichier récent				
Quit				
Exit without save				

EDIT :

Undo : not implemented yet.

Edit Pipe positions : Allows user to change pipe position by entering new **coordinates**.

Font

Font sizes

Register Windchest : Align all the pipes on the master stop, defined by the SLIDER keyword

DISPLAY :

Toolbar : displays toolbar

Status Bar : displays status bar.

Display 3D : displays the chest in a 3D representation.

Display chests : Displays chests positions; Allows editable XYZ spatial positions.

Vector mode : displays the chest only with lines.

Reset view 3D : resets initial chest position.

Rotate Organ : animates the full organ. Can be stopped by a left click.

Display infos : Displays magnet sizes, magnet number by size.

Display magnet sizes : displays or undisplay magnet sizes.

Toogle rotation axis : allows rotations around another rotation axis.

Masq dimensions : undisplay dimensions on the screen.

Mask Magnets : for slider chests.

Display	View	Create	?
<input checked="" type="checkbox"/> Toolbar			
<input checked="" type="checkbox"/> Status Bar			
Display 3D			
Display chests			
Vector Mode			
Rotate Organ			
Reset View 3D			
Display Infos			
Display Magnet sizes			
Toogle Rotation Axis			
Masq dimensions			
Masq Magnets			
Texture			
Color			
Grid			
Axes			

Texture : allows tin texture changes. Textures are given as .bmp files or .jpg files

Color :changes background color

Grid : displays a grid on the screen (10 cm)

Axes : displays organ and chest axes

CREATE :

Bar : creates a bar (under development)

OUTPUTS FORMATS :

CHEST DESIGNER generates the following files, if "*" is the windchest name :

*_fs.DXF FILE : is a DXF file for the false chest board. Can control directly an automated drilling machine.

*_som.DXF FILE : is a DXF file for the upper chest board.

*_mix.dxf for mixture windchests

*_commande.wri : contains the wood parts dimensions in millimeters for the whole chest.

UTenUT : Definition :

This control keyword can be inserted just after the "ENGLISH" keyword. It allows user to define pipe dimensions only by octave. Input process is 12 times faster and easier than pipe by pipe definition.

Followed by all above keywords. After, dimensions are given by

Pipe Diameter False chest diameter Hole diameter Pipe Height

One line corresponds to 12 pipes. But one must add a line more, for last pipes interpolation.

Chest Designer interpolates automatically pipe dimensions, following a given temperament.

Temperament table [12]=

{1.0535,1.1174,1.18518,1.25283,1.33333,1.40466,1.49493,1.58025,1.67044,1.77778,1.87924}

And used formula : let j beeing the note :

$D1 - ((D1 - D2) * (2 - ((1 / \text{tab_temp}[j]) * 2))))$

TOOLBAR : Symbols Definition :

- : Decelerate the rotation speed.
- : Accelerate the rotation speed.
- : Decelerate the translation speed.
- : Accelerate the translation speed
-  : Toogle rotation axis

TEXTURE FILES :

Basically, Chest Designer need 2 texture files :

tin.jpg for tin pipes

And

wood.jpg for wood pipes

Be carefull : these names are case-sensitive.
